Week 7 Lab Notes

A. Closed-loop motion control of the Robot

Objective

The purpose of this lab is to understand how to implement a closed-loop motion controller for mobile robot.

Learning outcomes


At the end of this exercise, you should be able to:

- Implement a Proportional Controller for a two-wheel mobile robot and let the robot reach a desired goal position.
- Assess the performance of the robot under the motion-based closed-loop control design.
- Observe and analyse the performance when the robot performing a continuous task.




Task 1: Preparation

- Download the 'driveToGoal.py' file from Ultra, and put it into the 'my_examples' folder.
- Open the GUI by running puzz_gui.py



• Select 'Module' with 'driveToGoal.py'. Note, there is no control program at this file.



Task 2: Motion Control

Implement a control algorithm to move the robot from its current position to an arbitrary goal point within the boundaries of the simulated world, following the next steps:

- Open 'driveToGoal.py' file.
- Set the goal point in line 16 and line 17, e.g., $\begin{bmatrix} x \\ y \end{bmatrix} = \begin{bmatrix} 2 \\ 1 \end{bmatrix}$.
- Write your code for Motion Control in the allocated section for this task

```
y puz guipy

Puzz guipy

Puzz
```

The following parameters are used in the program.

Parameter	Notation	Description
est_pose	μ _k	Robot pose mean (3x1) $[x\ y\ \theta]^T$ where $x[m], y[m]$ and $\theta[rad]$
self.target_x self.target_y	Xg	Goal point (2x1) $[x \ y]^T$
self.w_setR	$\omega_{ m r}$	Right motor speed set point. [rad/s]
self.w_setL	ωι	Left motor speed set point. [rad/s]
self.w_max	$\omega_{ ext{max}}$	Maximum angular speed of both the right and left wheels $[rad/s]$.
self.R	r	Radius of the wheels (0.05 $[m]$)
self.L	I	Robot wheel base (1x1) (0.09[m])
topics["IsDone"] = True		A command to stop the simulator.

Note that , self.w_setR and self.w_setL are the parameters to be updated by your code

• Run your code using GUI by clicking the icon •.



• Test your algorithm for different scenarios with different goal points.

Task 3: Real-Robot Experiments

Apply the motion control algorithm developed in Task 2 to a real robot, Puzzlebot.

You should follow the next steps to apply your control strategy to the robot:

 Check the IP address in the GUI and the robot IP address that is shown in the screen of the real robot. If they are different, change the IP address in the GUI to be the same as the one shown on the robot screen.



• Click the checkbox 'Connect'



• Run your code using GUI by clicking the icon •.

[End of Lab]